



Manual Addendum / Addendum au manuel

EN Included Motor and ESC**Motor:** Brushless Outrunner: KV3150 (FMMKV3150)**Installed****ESC:** 40A Brushless Switch Mode (FMMPAC113)**Installed****Recommended Flight Battery**

The manual on pages 3 and 8 is incorrect in regards to the battery required to fly this aircraft.

Incorrect: The current text states it requires a 4S 3300mAh, 3200mAh or a 6S 3200mAh LiPo battery.

Correct: The battery pack required is a **14.8V 2400mAh 4S 30C LiPo** battery (we recommend KXSB0016).

We apologize for any possible confusion.

FR Moteur et contrôleur inclus**Moteur:** Moteur sans balais Outrunner: KV3150 (FMMKV3150)**Installé****Contrôleur:** ESC 40A Switch Mode sans balais (FMMPAC113)**Installé****Batterie de vol recommandée**

Une erreur s'est glissée aux pages 18 et 23 du manuel au sujet de la batterie nécessaire au vol de cet appareil.

Erreur : Le manuel stipule qu'il faut une batterie LiPo 4S 3300 mAh ou 3200 mAh ou 6S 3200 mAh.

Rectification : La batterie requise est une **LiPo 14,8 V 2400 mAh 4S 30C** (nous recommandons le modèle KXSB0016).

Nos excuses pour toute confusion éventuelle.