

E-flite DRACO 2.0m Standard Transmitter Setup Details for Pre-Programmed Model Files

When using our standard 6 and 7 channel transmitter setups, the light controller is connected to channel 5/gear in the receiver and is assigned to the three-position B switch on your transmitter so you can toggle between three of the seven available light modes. On 8+ channel transmitters, channel 5/gear can be assigned to a rotary knob or slider so you can toggle between all seven light modes (also recommended if you prefer to control the lights independently of the optional-use SAFE Select/flight modes).

The optional-use motor reversing requires a 7+ channel transmitter. Motor reversing defaults to channel 7/aux 2 and is assigned to the two-position A switch when using our standard 7 and 8+ channel transmitter setups.

If you enable optional-use SAFE Select/flight modes with 6 and 7 channel transmitters, that will also need to be assigned to channel 5/gear and switch B. This means toggling between the SAFE Select and AS3X flight modes will also toggle the three light modes accordingly (as listed in the chart below). On 8+ channel transmitters, channel 8/aux 3 can be assigned to switch B or any other available switch you would like to use for SAFE Select/flight modes.

[- Download DX Gen2/3 Setups HERE -](#)

[- Download NX Setups HERE -](#)

[- Download iX Setups HERE -](#)

6-Channel Transmitter	Channel 5/Switch B	Optional Flight Modes/Switch B	Channel 6/Switch D	
DX6e; DX6 Gen 2/Gen 3 <i>Use file: Draco BNFB 6-Ch DX.SPM</i>	Pos 0: Light mode 7*	Pos 0: SAFE Select	Pos 0: Flaps up	*See the instruction manual for more info on the lights activated in each mode
	Pos 1: Light mode 4*	Pos 1: AS3X	Pos 1: Takeoff flaps	
	Pos 2: Light mode 1*	Pos 2: AS3X	Pos 2: Landing flaps	
7-Channel Transmitter	Channel 5/Switch B	Optional Flight Modes/Switch B	Channel 6/Switch D	Channel 7/Switch A
NX6 <i>Use file: Draco BNFB 7-Ch NX.NSPM</i> DX7 Gen 2 <i>Use file: Draco BNFB 7-Ch DX.SPM</i>	Pos 0: Light mode 7*	Pos 0: SAFE Select	Pos 0: Flaps up	Pos 0: Motor forward
	Pos 1: Light mode 4*	Pos 1: AS3X	Pos 1: Takeoff flaps	Pos 1: Motor reverse
	Pos 2: Light mode 1*	Pos 2: AS3X	Pos 2: Landing flaps	
8+ Channel Transmitter	Channel 5/Knob or Slider	Channel 6/Switch D	Channel 7/Switch A	Channel 8/Switch B
DX8e; DX8 Gen 2; DX9; DX10t; DX18; DX20 <i>Use file: Draco BNFB 8+ Ch DX.SPM</i> NX8; NX10 <i>Use file: Draco BNFB 8+ Ch NX.NSPM</i> iX12; iX20 <i>Use file: Draco_BNFB_8+_Ch_iX.ispm</i>	See the instruction manual for more info on the seven available light modes you can toggle between using the knob or slider	Pos 0: Flaps up	Pos 0: Motor forward	Pos 0: SAFE Select
		Pos 1: Takeoff flaps	Pos 1: Motor reverse	Pos 1: AS3X
		Pos 2: Landing Flaps		Pos 2: AS3X