




QUICKSTART GUIDE




1. Remove the Body




2. Remove the Vehicle Battery




3. Charge the Vehicle Battery




4. Reinstall the Vehicle Battery




5. Install the Transmitter Batteries




6. Power On the Transmitter




7. Power On the Vehicle




8. Reinstall the Body




9. Throttle/Brake




11. Throttle Limiter




10. Steering




12. Steering Rate




13. Steering Trim




14. Remove the Body



15. Power Off the Vehicle



16. Disconnect the Vehicle Battery



17. Power Off the Transmitter

