





QUICKSTART GUIDE




1. Remove the Body




2. Remove the Vehicle Battery




3. Charge the Vehicle Battery




4. Reinstall the Vehicle Battery




5. Install the Transmitter Batteries




6. Power On the Transmitter






7. Power On the Vehicle




8. Reinstall the Body





9. Throttle/Brake




12. Steering Rate




10. Steering




13. Steering Trim




Adjust as shown until vehicle tracks straight




11. Throttle Limiter




14. Remove the Body



16. Disconnect the Vehicle Battery



15. Power Off the Vehicle



17. Power Off the Transmitter

