

Version 1.07.14

New Features

- Faster Model Switching - new implementation of the model file format (iSPM v2) Greatly reduces time to switch between models
 - ***Please note*** Systems running older firmware (pre v1.07) that have not been updated will not directly import iSPM v2 model files. Make sure that both systems are updated using v1.07 or higher before transferring.
- Unique Volume Levels – Each category in the Audio Events Menu now has its own assignable volume level
- Model Category Edit - In the Model Setup menu, users have the ability to switch models between the 4 categories
- Custom Telemetry Dashboard – Multiple user scalable and customizable telemetry dashboard screens now available
- Updated D/R Expo Menu – a custom setup option was added to simplify standard setups or allow users to fully customize
- Expanded Combo Switches - Custom Audio Events can now use the Combo Switch function
- Improved Telemetry Configuration Screens – layout is improved with a more consistent look and feel
- Quick Telemetry Data Clear – Touch button has been added to the Dashboard that resets all stored active telemetry data (minimums and maximums on RPM, temp, voltage, etc.) and flight log data. Long press the signal icon “bars” on the top of the screen to reset the flight data
- Improved Model Import and Export function – improved User Interface for Import and Export function
- Swiwin turbine sensor telemetry now supported

Corrections & Improvements

- Telemetry file logging is now functioning properly
- 6 Aileron wing type now includes all available tail types
- Center Tones are no longer mistakenly included in SPM file export
- Inactivity Alarm is now more sensitive to small stick movements
- Elevator to flap mix in sailplane mode is now working correctly
- Analog Switches are now available in Switch Change Reports screen
- Switch and stick macros have been added
- Voice prompt is now present when override by the instructor is performed in Trainer mode
- Sequencer Gear selection is now working correctly.

2019-May 3



- Exporting Model crashes have been corrected.
- Telemetry Temperature display now displays "----" when the temperature sensor is not hooked up to the receiver. Previously with some receivers it read -129*.
- Vario telemetry tones have been improved with graduated tones for ascent and descent
- Telemetry display has been updated to correct several display bugs (fragment data, mislabel, etc.) for various telemetry options



Version 1.06.02

Corrections & Improvements

- In the previous build Version 1.06.01, a change was made that unintentionally prevented the ability to enter negative numbers in Telemetry Warning screens (RSSI, G Force, etc.), causing warnings to not function in these cases. This has been corrected in version 1.06.02.

Version 1.06.01

New Features

- The Model Adjust and Model Setup menu lists have been re-ordered with more frequently used functions located closer to the top.

Corrections & Improvements

- Wireless Trainer Instructor mode now maintains its bind even after the system is put into a full sleep.
- The "No Student Signal" trainer alert is now properly canceled when changing to a new model.
- In rare cases the RF would be modulating but LED would not be on. This has been corrected.
- In European languages, the Telemetry warning values can now use the comma separator for values like voltage, etc.
- Telemetry and Audio Event frequency values are now being maintained properly in languages other than English.
- In Aircraft Type the differential option has been removed in 1-Aileron 2-Flap configuration as only 1 aileron wing type should not allow for differential.
- The Signal Strength in the Flight Log tab would occasionally display RSSI although configured to display dBm. This has been corrected.
- The text on the Reset button in the System Settings screen has been changed from "Reset All Models" to "Reset Spektrum AirWare"
- The Telemetry Tab is no longer improperly being displayed after a Model Reset
- In the Digital Switch Setup screen the Reset buttons for Pos 0 and Pos 1 are now working properly.
- The Left/Right Sliders have been removed from the available options in Digital Switch Setup screen as they are not applicable to this function.
- The RF and CP processing is now handled more seamlessly when using Wired Trainer in Student Mode.
- The initial drop-down value in the Digital Switch Setup screen now says "Select" instead of "Inhibit" to help avoid confusion.

Version 1.05.03

Note: A bug has been identified that can cause an unusually long time (up to several minutes) to change models when using the quick model switch function from the Dashboard. Additional issues can include seeing a white screen during a model switch or in the Model Utilities screens. This issue only occurs if the “Dim the Display” function found in the Model Detail screen is set to anything other than “Never”. In addition when the “Dim the Display” function is set to anything other than never, the screen is not being properly dimmed. ****This update corrects this issue.****

Corrections & Improvements

- The “Dim the Display” function that was causing the delay and crashing issue has been removed.
- The Screen Brightness function has been moved to the System Configuration screen in System Settings.

Version 1.05.00

New Features

- The ability to assign a switch to cancel a timer has been added
- In Audio Events menu, the Macros for Rx Voltage functions now have their own group. Previously, RX Voltage was in the QOS group and was difficult to find.

Corrections & Improvements

- Assigned RSSI warning values are now properly being displayed
- Telemetry Warning Pop-up screens are now clearing more reliably
- Sequencer Default for Speed now properly defaults and resets to 5.0 seconds

Version 1.04.05

New Features

- **Forward Programming-** provides complete setup and adjustment of the AS3000 AS3X system when used with the PowerSafe Telemetry receivers. (Note that the Power Safe receiver firmware must be updated to 1.6 or above)
- **DX18 Compatibility Configuration** –supports upper channels (13-18) when transferring model files
- **Telemetry Flight Data Reset-** Provides ability to reset telemetry Data from the transmitter via on screen button
- **Telemetry Warning Screen-** displays when a telemetry warning threshold is exceeded. Clear button allow the alarm to be silenced.
- **Added Model Images-** More ready to use model images available for Acro, Heli and Multi

Corrections & Improvements

- **RSSI/Signal Strength-** is more accurately being displayed for Spektrum and CRSF receivers
- **Duplicate Audio Events-** Bug has been corrected
- **Direct Model Access-** selecting current model returns directly to Dashboard instead of reloading that model

Version 1.03.07

New Features

- **Quick Sleep Mode-** Battery life has been greatly enhanced in Quick Sleep Mode.
 - From the Sleep mode screen, access is available to turn WiFi and Bluetooth on/off. Long pressing the 'Quick Sleep' button will turn all options off and the system will enter "Full Sleep" mode in about a minute.
 - To minimize current consumption the LED will no longer have the 'heartbeat' indication of sleep mode. A single press of the power button returns to normal operation, and any options in the sleep mode screen that were turned off by entering Sleep Mode will be turned back on.
 - Note that the system will not enter Sleep mode if the system is connected to a computer's USB.
 - Note that in some cases the system will not enter "Full Sleep" if an SD Card is in the radio, a warning will appear if a SD card is detected.
- **Auto-Sleep** – After a prescribed amount of time of no user interaction, the iX12 will automatically enter Sleep Mode
 - Inactivity warning will take place first, then after user assigned time Sleep will start
 - This is adjustable in the System Settings > System Configuration Menu
- **Direct Model Access** – Long pressing the model select button at the top left hand corner of the dashboard now directly accesses the model change list. Then select the desired model and long press the Proceed button. The model will be loaded and the system will return to the Dashboard.
- **TBA Crossfire 2** w/ telemetry is now supported

Corrections & Improvements

- Telemetry File Logging is fully operational
- In App Battery Percentage – The in app percentage is now based purely on voltage of transmitter battery, not what is report via Android OS
 - This is much like what users are used to with non-smart transmitters
 - When users are running a Crossfire Modules, current draw is increased and will likewise show a drop in battery %
 - For best battery life when running external modules, tap power to turn off screen and or turn off 9.6v out when module is not in use
- When Voice settings are programmed in Audio Events and then the selection option is changed to Tone or Vibe, Voice settings are retained and are implemented when re-selection Voice or Voice Vibe.
- In Sailplane mode "mixing" Spoiler Stick has been added as an Input allowing greater flexibility in programming Camber changes.

Version 1.02.08

New Features

- Signal Strength can now be set to display Percentage, dBm or RSSI in the Flight Log telemetry screen
- In Sailplane mode, Throttle Stick has been added as an option in Flap to Elevator Mixing
- In Heli mode the pitch and throttle curve graphs now display the flight mode name such as Hold, Normal, Stunt 1, ect. instead of 0,1,2,3,4, allowing for easier identification of the selected flight mode
- Left and right sliders are now available as a switch option in the Switch Change Report
- In Heli Mode when active trims are selected for governor trim and/or Gyro Trim, the combined gain value (base gain + trim gain) is being displayed in the ().
- The option is available to have audio events announce first-in first-out or on demand

Corrections & Improvements

- Utilizing Crossfire Module, turning off the Display leaves the Crossfire RF ON.
- In Heli mode when Governor and/or Gyro active trim is programmed, the screen response has been improved
- Corrupted model files can no longer cause the App to enter a crash loop
- Voice/ Vibe options have been removed from the Trim Reports (but remain in the Trim Release reports)
- In Telemetry Warnings, ESC Motor Max current is now properly being displayed
- In Sailplane mode, when a Priority switch is programmed, the correct flight mode is now properly being announced when selected
- In Sailplane mode, when assigning flight modes to the Flap stick the mix values are now being properly retained
- In Sailplane mode when accessing the Telemetry dashboard, occasional crashes no longer occur
- During binding the Telemetry prompt voice announces at the correct time
- In many screens the Reset button resets the data back to the default rather than just 0
- When programming the flight controller gain on Blade helicopters like the Blade 180CPX, the selected value now properly displays - - -.
- Video Transmitter (VTX) settings are now functioning correctly and remain when exiting and re-entering that model.

2018-Jan-30



Version 1.01.03

Corrections & Improvements

- German Language Support- When selecting German as a Language, Spektrum AirWare is now stable.

Version 1.01.02

New Features

- When saving a model file as a Template, a message appears confirming that the model was successfully saved
- Telemetry Shortcut - On the Dashboard, when a telemetry screen is selected, long pressing the telemetry ICON at the top of the page will return to the Dashboard screen
- In Sailplane mode, when on the Flight Mode screen changing the flight display name also changes the name in the flight mode matrix for easier identification.
- Telemetry warnings for receiver voltage and Flight log are now displayed on the Audio Events Telemetry warnings screen
- **Update:** Vibe Duration- When Vibe is selected in the Audio Events or Timer Alerts, the option is now available to select the duration of the vibration. This allows discernable differences to be programmed for various alerts. (i.e. Short duration for 1 minute intervals and long duration for time expired.)

Vibe L= short duration

Vibe M= medium duration

Vibe H= long duration

Corrections & Improvements

- When switching to stick modes 1 or 3 the trim boxes displayed on the dashboard now properly switch to the correlating position of the trim switches
- The on screen response when adjusting the Dual Rate and EXPO values when using the sliders and + - buttons has been improved.
- Programmed mixes are now properly reset to defaults when inhibited.
- In Throttle Curve, the Throttle Delay button has been removed. Throttle Delay is only available in Throttle Cut. It was mistakenly displayed in the Throttle Curve screen in version 1.00.03



- Several timer issues have been corrected including the 1 minute timer announcement
- When using a Curve Mix the mix values now properly correlate to the servo output values on the servo monitor
- When using headphones or speakers, the audio is only output on the device and not the transmitter
- Several issues with the Sequencers have been corrected
- In Servo Setup - Speed, the right and left directions adjust the speed in that proper direction regardless of the servo reversing position
- In screens where the keyboard is available, the Cap lock defaults are now consistent.
- Battery transmitter voltage now displays in 1/10 volt increments at 4.0V.
- Model Timers now correctly trigger when reassigned to various switches and buttons.
- The Inactivity Alarm is no longer active when using other applications.
- Analog Switch setup now resets values correctly
- In the Model Start Alerts Servo Output screen all switch and stick options are now available
- When switching models, un-commanded random audio warnings no longer occur
- After setting up a Startup Warning, the system will now allow that model to be stored as a template
- In the Preflight Checklist, the option of Per Session now properly causes the checklist to activate only when the system is first powered on or a new model is selected and the RF is activated
- TBS Crossfire now properly turns on/ off during all phases including during charging



- Model Reset now resets the Model Name
- The startup tone now occurs when the Airware Application is up and ready to use
- When changing languages from another language back to English, the text for the TX battery and Inactivity alarms returns to English
- Telemetry RPM Macros now properly announce the RPM value
- In Helicopter Mode, when reversing the collective type the throttle warning now properly warns high throttle setting

iX12 Spektrum™ AirWare™ Change Log

2018-January-17



Version 1.00.03

Initial Release